


# SERVICE MANUAL

---

**KFR- 2688GW/BPE**




# 1.PART NAMES AND FUNCTIONS



This air conditioner consists of an indoor unit and an outdoor unit. You can control the air conditioner with the remote control unit.


<b>AirIntake</b>	Air from the room is drawn into this section and passes through air filters which remove dust.
<b>AirOutlet</b>	Conditioned air is blown out of the air conditioner through the air outlet.
<b>RemoteControlUnit</b>	The wireless remote control unit controls power ON/OFF, operation mode selection, temperature, fan speed, timer setting, and air sweeping.
<b>RefrigerantTubes</b>	The indoor and outdoor units are connected by copper tubes through which refrigerant gas flows.
<b>Outdoor(Condensing)Unit</b>	The outdoor unit contains the compressor, fan motor, heat exchanger coil, and other electrical components.
<b>DrainHose</b>	Moisture in the room condenses and drains off through this hose.

# 1.PART NAMES AND FUNCTIONS



<b>REMOTE CONTROL receiver</b>	This section picks up infrared signals from the remote control unit (transmitter)
<b>POWER lamp</b>	This lamp lights when the air conditioner is in the operation mode.(But the compressor may not run at this time.). NOTE:purple lamp is lighted in heating mode,blue lamp is lighted in other mode.
<b>TIMER lamp</b>	This lamp lights when the system is being controlled by the timer.
<b>RUN lamp</b>	This lamp lights when the compressor is electrified. NOTE:green lamp is lighted in low frequency;orange lamp is lighted in normal condition; red lamp is lighted in high frequency or high power mode.
<b>TEMPORARY SWITCH button</b>	This button is set for emergent state.Please use the remote control unit to operate the air conditioner in the common state.If you have lost the remote control unit or it has trouble, use this button to turn on/off your air conditioner.(See operation without the remote control unit.)

# 1.PART NAMES AND FUNCTIONS



**NOTE** The illustration above picture the remote control unit after the cover has been lowered and removed.

<b>Transmitter</b>	When you press the buttons on the remote control unit, the $\overline{\text{W}}$ mark appears in the display to transmit the setting changes to the receiver in the air conditioner.
<b>SENSOR</b>	A temperature sensor inside the remote control unit senses the room temperature.
<b>Display</b>	Information on the operating conditions is displayed while the remote control unit is switched on. If the unit is turned off, only the mode that was set previously is still displayed.
<b>SLEEP button</b>	For details, see Night Setback Mode . When you press this button, in the HEAT, DRY or COOL mode, the $\text{M}$ mark appears in the display, the remote control unit will automatically adjust the set temperature to save energy.
<b>TEMP. Setting buttons</b>	Press the $\Delta$ button to increase the set temperature. Press the $\nabla$ button to reduce the set temperature.
<b>ON/OFF operation button</b>	This button is for turning the air conditioner on and off.

## 2、 SPECIFICATION

<b>Model</b>			<b>KFR-2688GW/BPE</b>			
<b>Function</b>			<b>Cooling</b>	<b>Heating</b>		
<b>Power supply</b>			a.c 220V~230V/50Hz			
<b>Capacity</b>	<b>Capacity</b>		<b>kW</b>	<b>2.6</b>	<b>3.6</b>	
	<b>Dehumidification</b>		<b>l/h</b>	<b>1.0</b>	<b>—</b>	
	<b>Air flow</b>		<b>m<sup>3</sup>/h</b>	<b>380</b>	<b>400</b>	
<b>Electrical data</b>	<b>Power outlet</b>		<b>A</b>	<b>16</b>		
	<b>Running current</b>		<b>A</b>	<b>5</b>	<b>8</b>	
	<b>Power input</b>		<b>kW</b>	<b>0.9</b>	<b>1.25</b>	
	<b>Auxiliary heater</b>		<b>A(KW)</b>	<b>-</b>		
	<b>Starting current</b>		<b>A</b>	<b>22</b>		
	<b>Compressor motor current</b>		<b>A</b>	<b>5</b>		
<b>Coefficient of performance(C.O.P)</b>			<b>2.9</b>			
<b>Compressor</b>	<b>Model</b>		<b>C-1RB102H12AA</b>			
	<b>Output</b>		<b>W</b>	<b>550</b>		
	<b>Winding resistance (at20 )</b>			<b>T-R(1.326) T-S(1.360) R-S(1.268)</b>		
<b>Indoor fan motor</b>	<b>Model</b>		<b>YZW16W-4-411</b>			
	<b>Winding resistance (at20 )</b>			<b>340 ( main ) 395(assistant)</b>		
<b>Outdoor fan motor</b>	<b>Model</b>		<b>YDK29-62</b>			
	<b>Winding resistance (at20 )</b>			<b>Palm-white(230) white-pink(178)</b>		
<b>Dimensions</b>	<b>Indoor unit</b>	<b>Width</b>	<b>mm</b>	<b>805</b>		
		<b>Height</b>	<b>mm</b>	<b>186</b>		
		<b>Depth</b>	<b>mm</b>	<b>270</b>		
	<b>Outdoor unit</b>	<b>Width</b>	<b>mm</b>	<b>867</b>		
		<b>Height</b>	<b>mm</b>	<b>568</b>		
		<b>Depth</b>	<b>mm</b>	<b>290</b>		
<b>Weight</b>	<b>Indoor unit</b>		<b>kg</b>	<b>7.5</b>		
	<b>Outdoor unit</b>		<b>kg</b>	<b>35.0</b>		
<b>Refrigerant piping</b>	<b>Liquid pipe</b>		<b>mm</b>	<b>6.35</b>		
	<b>Gas pipe</b>		<b>mm</b>	<b>9.52</b>		
<b>Protection Level ( Outdoor unit )</b>			<b>IP24</b>			
<b>Special remarks</b>	<b>Max Press(Mpa)</b>		<b>4.15</b>			
	<b>Sound level (Hi)</b>	<b>Indoor unit</b>	<b>dB</b>	<b>39/33</b>		
		<b>Outdoor unit</b>	<b>dB</b>	<b>48/41</b>		
	<b>Fan speed (Hi)</b>	<b>Indoor unit</b>	<b>rpm</b>	<b>1230</b>		
		<b>Outdoor unit</b>	<b>rpm</b>	<b>785</b>		
	<b>Fan speed regulator</b>	<b>Indoor unit</b>	<b>3</b>			
		<b>Outdoor unit</b>	<b>3</b>			
	<b>Refrigerant filling capacity(R22A)</b>		<b>kg</b>	<b>0.7</b>		
	<b>Thermitstor</b>	<b>RT1(at25 )</b>	<b>k</b>	<b>58</b>		
		<b>RT2(at25 )</b>	<b>k</b>	<b>5.3</b>		
<b>RT3(at0 )</b>		<b>k</b>	<b>5</b>			

NOTE :Test conditions : Cooling : Indoor: DB27 / WB19

Heating: Indoor: DB20 / WB15


Outdoor DB35 /WB24

Outdoor DB7 / WB 6


# 4.PART NAMES AND FUNCTIONS

## 4 ELECTRIC WIRINGDIAGRAMS

### INDOORUNIT




### OUTDOORUNIT



# 5. REFRIGERANT SYSTEM DIAGRAM

KFR-2688GW/BPE




# 5.REFRIGERANT SYSTEM DIAGRAM

## MAX.REFRIGERANT PIPING LENGTH

Modles	Refrigerant Piping Max.Length:m A	Piping size (OD):mm		Lengthofconnectingpipe:m	
		Gas	Liquid	Indoor unit	Outdoorunit
KFR-2688GW/BPE	15	9.52	6.35		

## MAX.HEIGHT DIFFERENCE



## ADDITIONAL:REFRIGERANT CHARGE(R-410A: g)

Modles	Outdoor unitprecharged (up to 7m)	Refrigerant piping length (one way)		
		7m	10m	15m
KFR-2688GW/BPE	700	0	75	200

Calculation:  $Xg=25g/m*(A-7)m$



# 5. REFRIGERANT SYSTEM DIAGRAM

## EVACUATION PROCEDURES

Connect the refrigerant pipes (both the liquid and gas pipes) between the indoor and the outdoor units.


Remove the service port cap of the stop valve on the side of the outdoor unit gas pipe. (The stop valve will not work in its initial state fresh out of the factory (totally closed with cap)).

Connect the gag manifold valve and the vacuum pump to the service port of the stop valve on the gas pipe side of the outdoor unit.

Run the vacuum pump for more than 15 minutes and at this time confirm that the pressure gage indicates  $-0.1 \text{ Mpa} (-76 \text{ cmHg})$ .

Check the vacuum with the gag manifold valve, then close the gag manifold valve, and stop the vacuum pump.

Leave it as is for one or two minutes. Make sure the pointer of the gag manifold valve remains in the same position.



Remove the gag manifold valve quickly from the service port of the stop valve.

After refrigerant pipes are connected and evacuated, fully open all stop valves on gas and liquid pipe sides. Operating without fully opening lowers the performance and causes trouble.

Pipe length  
7m maximum  
No gas charge is  
needed.

Pipe length  
exceeding 7m  
Charge the prescribed  
amount of gas.

Tighten the cap to the service port to obtain the initial status.

Retighten the cap.

Leak test

## 6.CONTROL MODE

### 1.Display panel

1.1 Description of pattern

1.2 The display screen consists of 3 LEDs, indicating power, time set, operation.

1.3 Power indicator. When the air conditioner runs, the power indicator lamp lights up; Compressor operation indicator. When the compressor runs, the operation indicator lamp lights up;

1.4 Timer indicator. When the timer function works, the timer indicator lamp lights up;

### 2. Temporary Switch

2.1 Press the temporary switch to start the unit, and press it once again to stop the unit; the control unit makes a judge according to the room temperature to select the corresponding run mode. Once a run mode is selected, it will not be changed unless the unit is cut off and powered on again.

A. When the room temperature  $> 26$  , the unit starts in the cooling mode; the indoor controlled temperature is set at  $26$  , and the indoor fan speed is set to automatic mode;

B. When the room temperature  $< 23$  , the unit starts in the heating mode; the indoor controlled temperature is set at  $23$  , and the indoor fan speed is set to the automatic mode;

C. When  $23$  the room temperature  $26$  , the air blowing mode starts, and the indoor fan speed is set to automatic;

2.2 When the air conditioner is powered on, hold down the temporary switch for 5 seconds or longer, the control unit starts the test operation, when the system is forced to run in the cooling mode regardless of the room temperature.

2.3 Hold down the temporary switch and then turn on the air conditioner, the buzzer on the indoor unit rings two times, and the unit enters in the self-test status.

2.4 If a signal has been received from the remote controller during the temporary run, the system will operate according to the commands of the remote signal.

## 6.CONTROL MODE

### Automatic mode

3.1 When the remote controller is set to start the unit in the automatic mode, the air conditioner judges according to the differences between the room temperature and temperature setting and selects a run mode.

Indoor temperature  $\geq$  temperature setting, the unit runs in the cooling mode;

Indoor temperature  $<$  temperature setting, the unit runs in the heating mode.

3.2 The run mode is determined when the unit gets started at the first time. Once a mode is selected, it will not change within 30 minutes.

3.3 If the difference between the room temperature and temperature setting is above 3 , the run mode can be changed immediately.

3.4 When the unit is turned off and restarted with the remote controller, these conditions remain valid.

3.5 When powered off and powered on again, the air conditioner will reselect a run mode.

3.6 The indoor and outdoor fan speed and compressor control in the automatic mode are same as that in the heating and cooling mode.

3.7 After being set to the cooling only type in EE, the heating mode does not work.

### 4 Cooling mode

4.1 In the cooling mode, the temperature setting is selected by using the remote controller. The temperature control ranges from 16-30 .

4.2 When powered on for the first time, the compressor can be started immediately. After turning off, the compressor must not be restarted until at least 3 minutes later.

4.3 After turning on, the compressor must run for at least 5 minutes.

## 6. CONTROL MODE

Automatic:

	$T_{\text{setting}} - T_{\text{indoor}}$	Fan speed		$T_{\text{setting}} - T_{\text{indoor}}$	Fan speed
Direction of Temperature Difference	0	Mute	Direction of Temperature Difference	0	Mute
	1	Low		1	Low
	2	Low		2	Low
	3	Low		3	Low
	4	Low		4	High
	5	High		5	High

### 4.4 Outdoor fan speed

Single-speed motor starts or stops as soon as the compressor starts or stops.

4.6 The 4-way valve is interrupted.

4.7 Anti-freezing for evaporator

If 3 the indoor coil temperature 7

Frequency up restriction

If -1 the indoor coil temperature 3

Frequency down

If the indoor coil temperature -1

Compressor stops and displays the trouble

## 5. Dehumidification mode

5.1 In the dehumidification mode, the temperature setting is selected by using the remote controller. The temperature control ranges from 16-30 .

The control unit selects a run mode according to the temperature difference between the room temperature and temperature setting.

5.2 When the room temperature is above 2 higher than the temperature setting, the system runs in the cooling mode.

5.3 When the difference between the room temperature and temperature setting is equal to or lower than 2 , the system starts in the dehumidification mode. the compressor will alternate between the low (10minutes) and high(6minutes) frequencies.

5.4 When dehumidification, the outdoor fan starts or stops as soon as the compressor starts or stops.

## 6.CONTROL MODE

Outdoor temperature $\geq 28$ :	High
Outdoor temperature $< 28$ and condenser temperature $\geq 40$ :	High
Outdoor temperature $< 28$ and $40 >$ condenser temperature $\geq 35$ :	Mid
Outdoor temperature $< 28$ :	Low

### 6. Heating mode

- 6.1 In the heating mode, the temperature setting is determined with the remote controller. The temperature control ranges from 16-30 .
- 6.2 When powered on for the first time, the compressor may be started immediately. After turning off, the compressor must not be restarted until at least 3 minutes later.
- 6.3 After turning on, the compressor must operate at least 5 minutes.
- 6.4 When the air conditioner turns off, the compressor is interrupted; the outdoor 4-way valve turns off after a 1 minutes and 40 seconds delay; and the indoor fan stops after a 40 seconds delay to blow out the residual heat.
- 6.5 Cold air prevention function. When the air conditioner turns on, the indoor unit does not start immediately. When the heat exchanger temperature rises above 28 , the fan operates at the ultra-low fan speed, and the flap is opened to the position 1; when the heat exchanger temperature  $\geq 38$  or runs for over 4 minutes, the fan runs at a preset fan speed, and the flap is opened to a preset position. When the indoor heat exchanger temperature drops below 23 , the indoor fan stops.
- 6.6 When the unit is running, the indoor fan stops 40 seconds after the compressor is interrupted because the room temperature has reached the temperature setting. When the compressor is in operation again, the cold air prevention function still works.
- 6.7 In the heating mode, the outdoor fan starts or stops as soon as the compressor starts or stops unless the indoor heat exchanger overheat protection starts.

Outdoor temperature $\geq 24$ :	Low
15 Outdoor temperature $\geq 10$ :	Mid
Outdoor temperature $< 10$ :	High

6.8 The 4-way valve is activated.

6.9 Indoor heat exchanger overload protection

$T_{\text{indoor coil}} \geq 70$  , the compressor will stop;

$T_{\text{indoor coil}} \geq 55$  , the outdoor flow speed will turn to the low speed, and the compressor runs at the descending frequency;

$55 \leq T_{\text{indoor coil}} < 52$  , the compressor will prohibit the frequency from rising.

## 6.CONTROL MODE

### Automatic

		$T_{\text{setting}} - T_{\text{room}}$	Fan speed			$T_{\text{setting}} - T_{\text{room}}$	Fan speed
Direction of Temperature Difference		1	Low	Direction of Temperature Difference		1	Low
		2	Medium			2	Low
		3	Medium			3	Medium
		4	Medium			4	Medium
		5	High			5	Medium
		6	High			6	High

### 7 Defrosting mode (only applicable to the model with heat pump for cooling and heating).

7.1 Frost is removed by reverse of the 4-way valve.

7.2 Conditioner for entering in the defrosting mode:

when the heating mode continues for more than minutes and  $T_{\text{outdoor1}} - T_{\text{outdoor coil}} \geq 7$  for more than 5 minutes .

7.3 Defrosting procedures:

Both the compressor and outdoor fan motor are interrupted.

50 seconds later, the 4-way valve turns off.

5 seconds later, the compressor gets started.

$T_{\text{outdoor coil}} \geq 12$  or the compressor runs for more than 6 minutes, the compressor will stop.

30 seconds later, the 4-way valve turns on.

5 seconds later, compressor starts.

3 seconds later, outdoor fan starts.

Defrosting ends.

### 8. Fan mode

When select the fan mode,only both the indoor fan and flap operate in a preset mode. If the fan speed is set to “automatic”, the fan runs at the low speed.

## 6. CONTROL MODE

### Flap control

- 9.1 Press the up and down flap button, the flap's position is switched over between the 8 statuses, i.e. automatic flap, flap orientation where the flap plate opens to 6 positions 1, 2, 3, 4, 5, 6 from down to up, and flap swing.
- 9.2 Automatic flap: In the heating mode, the flap swings between position 1 and position 4; In the cooling or dehumidification mode, the flap swings between position 3 and position 6; In the fan mode, the flap is located at position 5.
- 9.3 Flap orientation: The flap is set at a certain position by using the remote controller.
- 9.4 Flap swing: The flap swings between position 1 and position 6.
- 9.5 The default status is the "automatic flap".
- 9.6 When powered on and off for the first time, the flap plate turns to the maximum angle to ensure that the flap is closed; When the unit starts, the flap plate moves to the maximum angle, and returns to the preset position after the flap is completely closed.

### 10. Man-machine communication

- 10.1 The indoor control unit has two thermal sensors for detecting the room temperatures, one is installed in the remote controller, and the other at the air intake of the indoor unit. The default air outlet setting is subject to the remote controller's detection. The remote controller detects the room temperature once every 20 seconds, and automatically transmits the signal at 3-minute intervals or when it has detected a change in the room temperature. If the indoor control unit has not received a remote signal for more than 10 minutes, the control function will be automatically switched over to the temperature sensor at the air intake.
- 10.2 Neither turning on nor turning off operations will cancel the man-machine communication function.
- 10.3 In default, the air conditioner is set to start the man-machine communication function.

### 11. Timer function

- 11.1 Timer on: When set to start in the set time with the remote controller, the air conditioner enters in the timer on status. When the set time is up, the air conditioner turns on and operates according to the preset conditions after receiving the signal from the remote controller. If the air conditioner has not received the signal of the remote controller when the set time is up, it will automatically start and operate according to the preset conditions.
- 11.2 Timer off: When set to stop in the set time with the remote controller, the air

## 6.CONTROL MODE

conditioner enters the timer off status. When the set time is up, the air conditioner turns off after receiving the signal from the remote controller. If the air conditioner has not received the signal of the remote controller when the set time is up, it will turn off automatically.

11.3 Neither turning on nor turning off operations will cancel the timer function.

### 12. Sleep function

12.1 In the heating or cooling mode, press the “Sleep” button on the remote controller to start or cancel the sleep function in sequence.

12.2 In the heating mode, 1 hour after the sleep mode starts, the temperature setting will decrease by 3 . After another 2 hours, the temperature decreases by 4 further. The unit will continue to run for further 5 hours and then stops automatically.

12.3 In the cooling mode, 1 hour after the sleep mode starts, the setting temperature will rise by 1 . The unit will continue to run for further 7 hours and then automatically stops.

12.4 In default, the preset status is to cancel the sleep function. Turning off the unit will also cancel the sleep function.

**Note: This function is subject to the description in the User’s Manual.**

### 13. Instruction of troubleshooting


When the air conditioner works in the abnormal condition, please press the sensor button of the remote controller one time and then press this button continuously two time, the trouble (the LED lamp lights up or flickers) will be displayed on the display panel.

Content of trouble	LED lamp			
	Timer lamp	Running lamp ( blue )	Running lamp(red)	Power lamp
Indoor sensor trouble				
Evaporator sensor trouble				
Evaporator freezing				
Over hot of indoor heat exchanger				
Communication trouble				
Power failure instantaneously				
Over current of compressor				
Fan motor trouble				
Outdoor sensor trouble				
Outdoor coil sensor trouble				



Over current of whole system				
No load				
Abnormal power voltage				
Overload of outdoor unit for cooling				
Defrosting				
IPM trouble				
Data failure of outdoor E <sup>2</sup> PROM				

# 7 INDOOR CONTROL BOARD





# 8.SENSOR PARAMETER

## THE PARAMETER OF THE INDOOR SENSOR

T('c)	R(Ko)	V(v)	T('c)	R(Ko)	V(v)	T('c)	R(Ko)	V(v)
-10	27.68	0.7258	7	11.52	1.4488	24	5.226	2.3675
-9	26.22	0.76	8	10.97	1.4997	25	5	2.4227
-8	24.85	0.7953	9	10.45	1.5512	26	4.785	2.4776
-7	23.56	0.8316	10	9.963	1.6027	27	4.581	2.5321
-6	22.34	0.8691	11	9.497	1.6553	28	4.387	2.5861
-5	21.19	0.9077	12	9.056	1.7083	29	4.202	2.6399
-4	20.11	0.9472	13	8.638	1.7619	30	4.025	2.6934
-3	19.09	0.9878	14	8.241	1.8159	31	3.857	2.7463
-2	18.12	1.0298	15	7.865	1.8703	32	3.697	2.7986
-1	17.21	1.0726	16	7.508	1.925	33	3.545	2.8502
0	16.35	1.1164	17	7.169	1.9799	34	3.399	2.9016
1	15.54	1.1611	18	6.847	2.0352	35	3.26	2.9523
2	14.77	1.207	19	6.541	2.0906	36	3.128	3.002
3	14.05	1.2533	20	6.251	2.1459	37	3.002	3.0512
4	13.36	1.3012	21	5.975	2.2014	38	2.881	3.0999
5	12.72	1.349	22	5.712	2.257	39	2.766	3.1476
6	12.1	1.3988	23	5.463	2.3123	40	2.657	3.1942

## THE PARAMETER OF THE COIL AND OUTDOOR SENSOR

T('c)	R(Ko)	V(v)	T('c)	R(Ko)	V(v)	T('c)	R(Ko)	V(v)
-20	39.58	0.5307	9	10.1	1.5878	38	3.265	2.9504
-19	37.58	0.5558	10	9.684	1.6338	39	3.151	2.9932
-18	35.69	0.5818	11	9.284	1.6805	40	3.041	3.0358
-17	33.91	0.6087	12	8.903	1.7276	41	2.936	3.0775
-16	32.23	0.6363	13	8.54	1.7749	42	2.835	3.1188
-15	30.65	0.6648	14	8.194	1.8226	43	2.739	3.159
-14	29.15	0.6942	15	7.864	1.8704	44	2.646	3.199
-13	27.74	0.7244	16	7.549	1.9185	45	2.556	3.2387
-12	26.4	0.7556	17	7.249	1.9667	46	2.471	3.2771
-11	25.14	0.7875	18	6.962	2.0151	47	2.388	3.3155
-10	23.95	0.8202	19	6.688	2.0636	48	2.309	3.3528
-9	22.82	0.8539	20	6.427	2.112	49	2.233	3.3896
-8	21.75	0.8885	21	6.178	2.1603	50	2.159	3.4262
-7	20.74	0.9237	22	5.939	2.2089	51	2.089	3.4615
-6	19.79	0.9596	23	5.712	2.257	52	2.021	3.4965
-5	18.88	0.9966	24	5.494	2.3053	53	1.956	3.5306
-4	18.02	1.0343	25	5.286	2.3533	54	1.893	3.5644
-3	17.2	1.0731	26	5.086	2.4014	55	1.832	3.5977
-2	16.43	1.1122	27	4.896	2.4489	56	1.774	3.6299
-1	15.7	1.152	28	4.714	2.4963	57	1.718	3.6616
0	15	1.1929	29	4.539	2.5436	58	1.664	3.6926
1	14.34	1.2342	30	4.372	2.5904	59	1.612	3.7231
2	13.71	1.2765	31	4.212	2.6369	60	1.562	3.7528
3	13.11	1.3195	32	4.059	2.683	61	1.513	3.7824
4	12.55	1.3623	33	3.912	2.7288	62	1.467	3.8106
5	12.01	1.4063	34	3.772	2.7738	63	1.422	3.8386
6	11.5	1.4506	35	3.637	2.8188	64	1.379	3.8658
7	11.01	1.4959	36	3.508	2.8631	65	1.337	3.8927
8	10.55	1.541	37	3.384	2.907			

## 8.SENSOR PARAMETER

### THE PARAMETER OF THE DISCHARGE SENSOR

T('C)	R(O)	V(v)	T('C)	R(O)	V(v)	T('C)	R(O)	V(v)
-10	313.4	0.3	31	44.74	1.545	71	9.659	3.372
-9	297.2	0.315	32	42.89	1.59	72	9.331	3.409
-8	281.9	0.331	33	41.13	1.636	73	9.016	3.446
-7	267.5	0.348	34	39.44	1.682	74	8.712	3.483
-6	253.9	0.365	35	37.84	1.729	75	8.421	3.519
-5	241.1	0.383	36	36.3	1.776	76	8.14	3.554
-4	229	0.402	37	34.84	1.823	77	7.869	3.588
-3	217.6	0.421	38	33.44	1.871	78	7.609	3.622
-2	206.8	0.441	39	32.11	1.919	79	7.359	3.655
-1	196.6	0.462	40	30.83	1.967	80	7.118	3.688
0	186.9	0.483	41	29.61	2.016	81	6.885	3.72
1	177.8	0.506	42	28.45	2.064	82	6.662	3.751
2	169.2	0.529	43	27.34	2.112	83	6.446	3.781
3	161	0.552	44	26.27	2.161	84	6.239	3.811
4	153.3	0.577	45	25.25	2.21	85	6.039	3.84
5	146	0.602	46	24.28	2.258	86	5.846	3.869
6	139	0.629	47	23.35	2.307	87	5.661	3.897
7	132.5	0.656	48	22.46	2.355	88	5.482	3.924
8	126.3	0.684	49	21.6	2.404	89	5.309	3.951
9	120.4	0.712	50	20.79	2.452	90	5.143	3.977
10	114.8	0.742	51	20.01	2.499	91	4.982	4.003
11	109.5	0.772	52	19.26	2.547	92	4.827	4.028
12	104.4	0.804	53	18.54	2.595	93	4.678	4.052
13	99.66	0.836	54	17.85	2.642	94	4.534	4.076
14	95.13	0.869	55	17.19	2.689	95	4.395	4.099
15	90.82	0.902	56	16.56	2.735	96	4.261	4.122
16	86.74	0.937	57	15.96	2.781	97	4.132	4.144
17	82.85	0.972	58	15.38	2.826	98	4.007	4.165
18	79.16	1.008	59	14.82	2.872	99	3.886	4.187
19	75.65	1.045	60	14.29	2.916	100	3.77	4.207
20	72.32	1.083	61	13.78	2.96	101	3.658	4.227
21	69.15	1.122	62	13.28	3.005	102	3.549	4.246
22	66.13	1.161	63	12.81	3.048	103	3.444	4.265
23	63.27	1.201	64	12.36	3.09	104	3.343	4.284
24	60.54	1.242	65	11.93	3.132	105	3.15	4.32
25	57.94	1.283	66	11.51	3.174	106	3.059	4.337
26	55.46	1.325	67	11.11	3.214	107	2.97	4.354
27	53.11	1.368	68	10.73	3.254	108	2.884	4.37
28	50.86	1.411	69	10.36	3.294	109	2.802	4.386
29	48.72	1.455	70	10	3.333	110	2.721	4.401
30	46.68	1.5						